



1. GLUE 1/32\"/>
2. REFERENCE LINE SHOULD BE DRAWN ON FUSELAGE SIDES. IT IS RECOMMENDED THAT YOU MAKE THIS A COLOR LINE. THIS WING & STAB SET UP CAN BE CHECKED AFTER PLANE IS FINISHED.
3. DIMENSIONS SHOWN ON PLANS FOR SETTING WING & HORIZ. STAB ARE MEASURED FROM C/L OF LEADING & TRAILING EDGES.
4. FOR A MORE DOG-EYE FLYING PLANE SET WING & HORIZ. STAB AT 0 DEGREES INCIDENCE.
5. ADJUST LANDING GEAR TO SET WING C/L LEADING EDGE 1/8\"/>
6. ORIGINAL PLANE HAS WING DOG-EYE KEYS & NYLON SCREWS. DOG-EYES ARE SHOWN IN FUSELAGE ON PLANS AS ALTERNATE WING HOLD-DOWNS.