


To join wing plan, remove page 34 and 35 from magazine and join together. Remove page 37 and join to right hand side of page 35. To construct fuselage, join top of page 38 to bottom of page 36. Join top of page 39 to bottom of page 38. Join top of page 41 to bottom of page 39.



(SEE TEXT) INLAY  
3/8" SQ. 1/16" PLY  
FOR CABANE  
HOLD DOWN

1/16" SHEET BALSA  
PLANKING TO HERE  
TOP & BOTTOM  
OF LOWER WING  
ONLY

3/8" SQ.  
BALSA L.E.

3/8" SQ.  
L.E.

3/8" SQ.  
L.E.

VERY HARD  
1/8" SHEET SPARS

TAPERED  
T.E. STOCK

1/4" SHEET BASSWOOD  
RIB DOUBLER  
TOP & BOTTOM WING

1/8" SHEET  
BALSA SPARS

1/16" SHEET  
BALSA RIBS

1/8" SHEET  
BALSA SPARS

1/4" SHEET  
BASSWOOD  
DOUBLERS  
TOP & BOTTOM

1/16" SHEET  
BALSA RIBS

BICYCLE SPOKE

ALUMINUM  
TUBING

NOTE:  
BOTTOM WING HAS  
1/2" PER PANEL  
DIHEDRAL AND TOP  
WING IS FLAT  
(0° DIHEDRAL)

1/16" SHEET  
BALSA RIBS

3/4" TAPERED  
TRAILING EDGE  
STOCK  
(TOP WING ONLY)

1/4" SQ. T.E.  
BOTTOM WING  
ONLY

1/4" SQ.  
BALSA T.E.

3/4" TAPERED  
T.E. STOCK  
(TOP WING ONLY)

1" X 1" X 7"  
BALSA TIPS

LAMINATE  
1/8" BALSA  
STRUT (3 LAYERS)

3/32" I.D.  
TUBING

3/32" MUSIC WIRE

1" TAPERED  
T.E. STOCK  
AILERONS  
(BOTTOM WING  
ONLY)

BICYCLE  
SPOKE  
NIPPLE

1" TAPERED T.E. STOCK AILERON (BOTTOM WING ONLY)

